



TORO-IRRIGATION DIVISION 5825 JASMINE STREET RIVERSIDE, CA 92504 TOLL FREE: 1-877-345-8676 FAX: (951) 359-1870 www.toro.com

1 TORO SENTINEL
IRRIGATION CONTROLLER
MODEL NO. SBDWS5U (DC)
OR SBAWS5U (AC)

SEE PLANS FOR NUMBER OF STATIONS

ANCHOR SECURLY TO WALL

- 2 3/4" CONDUIT FOR ELECTRICAL POWER CONDUCTORS PER LOCAL AND NATIONAL CODES
- 3 2" CONDUIT FOR TWO-WIRE PATH

 SECURE TO WALL WITH APPROPRIATE
 PIPE CLAMPS
- (4) 3/4" CONDUIT FOR EARTH GROUND
- (5) FINISHED SURFACE
- (6) 1/2" CONDUIT FOR SENSOR WIRES
- 7 OPTIONAL 2" CONDUIT FOR SECOND TWO-WIRE PATH
- 8 STANDARD 400MHZ ANTENNA FOR PRIMARY COMMUNICATION
- 9 900MHZ ANTENNA FOR OPTIONAL WIRELESS SOIL SENSOR ADD-ON MODEL NO. TPS-RX
- (10) OPTIONAL OMNI DIRECTIONAL ANTENNA PER SITE SURVEY RECOMMENDATIONS MODEL NO. SB-ANT-MAST
- (11) OPTIONAL 1-1/2" CONDUIT FOR ANTENNA WIRE MINIMUM RADIUS ON SWEEP SHALL BE 1-1/2"

NOTES:

- 1. INSTALLATION TO BE COMPLETED IN ACCORDANCE WITH MANUFACTURERS SPECIFICATIONS.
- 2. DO NOT SCALE DRAWINGS.
- CONTRACTORS NOTE: FOR PRODUCT AND COMPANY INFORMATION VISIT www.CADdetails.com/info REFERENCE NUMBER 065-121.



SENTINEL TWO-WIRE WALL-MOUNT CONTROLLER

WS5 STAINLESS STEEL CABINET